

BEFORE YOU BEGIN

WARNING

Make sure power is **OFF** at the breaker before starting installation or any maintenance.

SAFETY

This driver must be wired in accordance with local electrical codes and ordinances. All work should be done by a qualified electrician.

NOTE

Read all instructions before installing. Keep this sheet for future reference.

INSTALLATION

- 01 Turn off power at the breaker.
- 02 Remove the terminal covers on the driver.
- 03 Connect **Black** to **Hot** and **White** to **Neutral** on the high-voltage side.
- 04 Connect **+** to the positive wire and **-** to the negative wire on the low-voltage side.
- 05 Restore the covers and energize.

WIRING REFERENCE

| | |
|---------------------------------------|----------|
| <input type="checkbox"/> Hot / Line | BLACK |
| <input type="checkbox"/> Neutral | WHITE |
| <input type="checkbox"/> Positive (+) | LOW VOLT |
| <input type="checkbox"/> Negative (-) | LOW VOLT |