

## BEFORE YOU BEGIN

### WARNING

Make sure power is **OFF** at the electrical panel before starting installation or any maintenance. Indoor installation only unless otherwise noted.

### SAFETY

This fixture must be wired in accordance with local electrical codes and ordinances. All work should be done by a qualified electrician.

### NOTE

Read all instructions before installing. Keep this sheet for future reference.

## MODULE SIZES

MODULE	LENGTH	SECTION
Short	5-1/2" × 1-2/5"	139 × 36 mm
Medium	10-3/4" × 1-2/5"	272 × 36 mm
Long	11-3/5" × 2-1/3"	296 × 60 mm
XL	12-3/5" × 3-1/4"	320 × 82 mm

## RECESSED INSTALLATION

- 01 Determine the location for installation and cut ceiling hole in accordance with cut-hole dimensions.
- 02 Open the junction box cover and remove the appropriate knockout(s) on the side panel. Connect all wires on the junction box. Select the light color temperature: 2700K · 3000K · 3500K · 4000K · 5000K. Insert junction box through the mounting hole. (FIG. 2)
- 03 Wire power into the provided junction box.
- 04 Mount the Built-in Fitting into the ceiling; tighten screws to lock it. (FIG. 3)
- 05 Paint the ceiling 2–3 times to make it smooth. (FIG. 3)
- 06 Connect the driver with the lamp body. Connect the metal safety rope buckle. (FIG. 4)
- 07 Press the trim to lock the lamp with the built-in fitting. (FIG. 4)
- 08 Turn on the light to test. (FIG. 4)

## FIGURES

**FIG. 1**

Fig. 1 - Dimensioni di perforazione	
5 GHz	50x50x100 (20x20x40)
10 GHz	100x100x100 (40x40x40)

Fig. 1 · Cut-hole dimensions

**FIG. 2**

Fig. 2 · J-box wiring & CCT switch

**FIG. 3**

Fig. 3 · Built-in fitting & paint

**FIG. 4**

Fig. 4 · Driver, trim & test