



LED LINEAR LIGHT

D. Dimension drawing




E. Installation

Fix the brackets via M4 tapping screws, mounting size as below:




F. Connection

A signal amplifier is required for the number of luminaire connections of 60 or 100 meters



Mode No.	Input voltage	Power Connection Qty (30W)	Signal Connection Qty(RGBW: 4CH)
LLS-WZB-W40-L12	120V AC	20 PCS	128 PCS
LLS-WZB-W40-L12	240V AC	40 PCS	128 PCS



Caution:

1. Do not plug them into power when the product is still in package;
2. Don't use anything to cover the fixture during application;
3. Don't use this product in close environment;
4. If this product appears to be damaged, do not attempt

Warning:

- * Neglect on action of the above treatment will lead to failure of waterproof and proper working of the lights!!!
- * Make sure the ground connection well avoid electric shock, due to metal housing.

The above instruction are subject to update or improved without notice. Pls turn to our staff for further details !
Thanks for your long term support !