

BEFORE YOU BEGIN

WARNING

Make sure power is **OFF** at the electrical panel before starting installation or any maintenance. Indoor installation only unless otherwise noted.

SAFETY

This fixture must be wired in accordance with local electrical codes and ordinances. All work should be done by a qualified electrician.

NOTE

Read all instructions before installing. Keep this sheet for future reference.

INSTALLATION

- 01 Cut out the ceiling according to the size cutout of the size fixture you are installing. (FIG. 1)
- 02 Set the CCT switch inside the junction box to the desired color temperature. (FIG. 6)
- 03 Make electrical connections inside the supplied junction box: black-black, white-white, ground-green. (FIG. 2)
- 04 Connect the panel's quick-connector to the junction box pigtail. (FIG. 3)
- 05 Squeeze the spring clips on the panel together and push the assembly up into the ceiling cut-out. (FIG. 4)
- 06 Release the spring clips so they catch above the drywall; press the panel flush against the ceiling.
- 07 Restore power and verify operation.

CCT SELECTOR

<input type="checkbox"/>	2700K — Warm white	POS 1
<input type="checkbox"/>	3000K — Soft white	POS 2
<input type="checkbox"/>	3500K — Neutral white	POS 3
<input type="checkbox"/>	4000K — Cool white	POS 4
<input type="checkbox"/>	5000K — Daylight	POS 5

FIGURES

<p>FIG. 1</p>	<p>FIG. 2</p>	<p>FIG. 3</p>
<p>Fig. 1 · Cut 4-1/4" hole in ceiling</p>	<p>Fig. 2 · Wiring inside junction box</p>	<p>Fig. 3 · Quick-connect to pigtail</p>
<p>FIG. 4</p>	<p>FIG. 5</p>	<p>FIG. 6</p>
<p>Fig. 4 · Spring-clip push into ceiling</p>	<p>Fig. 5 · Dry / Damp rating diagram</p>	<p>Fig. 6 · CCT switch positions 2700K–5000K</p>